

# Adhesive Recommendations

Australian Edition

Product	Note	Normal Installations	High Temperature / Humidity Installations
Carpet Tiles and Planks		GS GHM444 Mapei: Ultrabond Eco tack	
Laminate Floors	Stairs only (Treads, Risers, Nosing)	Construction Adhesive (Liquid Nails®) Mapei: Ultrabond Eco S955 1K	Mapei: Ultrabond Eco S955 1K
Vinyl Plank Floors	All Constructions/Types	RLA Polymer: 265 Hard-Set Mapei: Ultrabond Eco V4 SP Mapei: Ultrabond Eco V4 Evolution Mapei: Ultrabond Eco VS90plus	RLA Polymer: RLA HT280 Hard-Set Mapei: Ultrabond Eco MS 4 LVT Wall
Hybrid Floors	Stairs only (Treads, Risers, Nosing)	Construction Adhesive (Liquid Nails®) Mapei: Ultrabond Eco S955 1K	RLA Polymer: RLA HT280 Hard-Set Mapei: Ultrabond Eco MS 4 LVT Wall
Timber Floors	Direct stick installations	Bostik: Ultraset RLA Polymer: RLA 1017 Sika: T55 Mapei: Ultrabond Eco S955 1K	
Timber Floors	Floating Installations: T&G Joint Adhesive	Proprietary Cross-Linked PVA Adhesive	
Accessories		Construction Adhesive (Liquid Nails®) Mapei: Ultrabond Eco S955 1K	

## Notes:

1. Always follow the adhesive manufacturers directions.
2. High Temperature (HT) installations are those areas where, either geographically or in the built environment, the flooring will be exposed to high and/or large variations in temperature, direct heat, sunlight or humidity.
3. Pressure Sensitive Adhesives are not recommended and may void the flooring warranty. Where the installation requires this type of adhesive, seek specialist advice from your adhesive supplier.
4. Specialist installations, such as vinyl plank over an acoustic underlay, require specialist adhesive advice. Contact your adhesive supplier.
5. Use of non-recommended adhesives may void the product warranty. Any warranty claim must be accompanied with proof of adhesive used.